


HCM-1

Camera Wall Mount - Small Base Set Up Guide





What's Included



2) Qty 1 - 1/4 20 x 3/8"

3) Qty 2 - 1/4" washer

4) Qty 4 - #10 x 1 1/4" screws

5) Qty 4 - #10-12 x 1" conical plastic anchors

6) Qty 4 - #6-32 x 1" screws

7) Qty 4 - #6 washers







STEP 1.

For masonry or drywall wall:

Position on wall and mark wall for anchor placement. Pre-drill 1/4" holes, minimum 1" deep.

For double gang electrical box:

Position over box with slots overlaying device mounting holes in box.

STEP 2.

For masonry or drywall wall:

Place included anchors in wall and mount to anchors using included #10 screws.

For double gang electrical box:

Mount to box using #6 screws and washers provided.

STEP 3.

Drill hole in wall through rear exit opening for cable access, or use base exit opening.

STEP 4.

Mount camera to mount with included ¼-20 screw. Utilize (0, 1 or 2) 1/4" washers as required, depending upon depth of threaded insert in base of the camera, in order to achieve a snug fit. Connect all cables.



